

HolstonTV



HOW TO PROGRAM YOUR HOLSTONTV REMOTE FOR TV AND AUDIO CONTROL:

TV Code Entry

The Remote Control can be manually programmed with a TV code. To program this code, use the following sequence:

- Press and hold <setup> for 3 seconds, until the LED turns green
- Enter 5 digit code sequence, always starting with a <1>
- Successful completion is signalled by 2 green blinks
- When an incorrect code is entered, the led will be red for 2 seconds

Code Reset

The configured TV codes can be reset to its factory default using the following sequence:

- Press and hold <setup> for 3 seconds, until the LED turns green
- Press <9> <8> <6>
- Successful completion is signalled by 2 green blinks

Send volume control to TV or other Audio Device

The Remote Control can be toggled to send volume control to the TV; this function will only be successful when the Remote Control has a valid TV Code selection; to send volume control to the TV, use the following sequence:

- Press and hold <setup> for 3 seconds, until the LED turns green
- Press the Volume Up button
- Successful completion is signalled by 2 green blinks

Factory Reset

At any time, the Remote Control can be returned to the factory reset state using the following sequence:

- Press and hold <setup> for 3 seconds, until the LED turns green
- Press <9> <8> <1>

TV

Maker (Brand) Name	CodeNumber(5digit)List										
3M	10368										
A MARK	10103	10132	10388								
ACTION	10370										
ADMIRAL	10436	10431									
ADVENT	10135	10339									
ADVENTURA	10372										
AFTRON	10373										
AIKO	10374										
AIWA(R-44A)	10082	10183									
AKAI	10148	10160	10001	10317	10318	10348	10352	10542	10439	10476	10517
ALARON	10376										
ALBATRON	10377										
AMBASSADOR	10378										
AMERICA ACTION	10380										
AMPRO	10070	10164	10249	10381							
AMSTRAD	10053										
ANAM	10045	10055	10057	10076	10095	10099	10103	10109	10112	10143	10380
AOC	10088	10363	10367	10001	10011	10103	10330	10439			
AOMNI	10354										
APEX	10302	10303	10282								
APEX DIGITAL	10303	10373	10384								
ARCHER	10388										
ASTAR	10390										
AUDIOVOX	10345	10319	10380	10374	10388						
AURORA SYSTEMS	10391										
AVENTURA	10311										
BELCOR	10001	10011	10315								
BELL & HOWELL	10393										
BENQ	10395	10396									
BLAUPUNKT	10084										
BLU-SENS	10476	10455	10499								
BRADFORD	10380										
BRIILLIAN	10398										
BROCKWOOD	10011	10315									
BROKSONIC	10143	10166	10174	10431							
BUSH	10399										
BYD-SIGN	10400										
CANDLE	10001	10002	10003	10011	10439	10372	10543				
CANON	10402	10403									
CAPEHART	10059										
CARNIBALE	10001	10439									
CARVER	10415	10405									
CASIO	10406	10407									
CCE	10408										
CELEBRITY	10409										
CELERA	10303										
CETRONIC	10045										
CHANGHONG	10303										
CITIZEN	10001	10002	10003	10011	10045	10092	10094	10132	10439	10374	10372
	10543	10517									
CLARION	10380										
CLASSIC	10045										
COBY	10412	10011	10275								
COMM. SOLUTIONS	10413										
COMPAQ	10414										
CONCERTO	10011	10543									
CONTEC	10041	10045	10051	10052	10380						
CORENA SYSTEM	10301										
CORONADO	10132										
CRAIG	10045	10055	10157	10049	10159	10380	10258				
CROSLLEY	10415										
CROWN	10045	10132	10380								
CURTIS MATHES	10001	10092	10011	10132	10365	10413	10415	10393	10319	10436	10542
	10439	10368	10504	10543	10271						
CXC	10045	10380									
CYBERHOME	10416										
CYTRON	10417	10418									
DAEWOO	10011	10022	10023	10038	10045	10046	10056	10068	10073	10094	10098
	10102	10105	10108	10111	10114	10116	10118	10119	10127	10132	
	10246	10319	10374	10315	10188						
DAYTRON	10011	10132	10315								
DELL	10148	10314									
DELTA	10419										
DENON	10368	10421									
DIAMOND VISION	10422	10423									
DIGI LINK	10172										
DIGISTAR	10424										
DIGITAL LIFESTYLES	10425	10426									
DIG. PROJECTION INC.	10427	10429									
DREAM VISION	10430										
DUMONT	10011										
DURABRAND	10431	10380	10315	10311	10434	10388	10435				
DWIN	10436										
DYNASTY	10045										
DYNATECH	10063										
DYNEX	10091	10347	10366								
EIKI	10253	10402									
ELECTROGRAPH	10354										
ELECTROHOME	10074	10132	10431								
ELECTROBAND	10409										
ELECTROGRAPH	10486	10354									
ELEMENT	10335	10259	10273	10283							
	10001	10012	10013	10029	10033	10045	10048	10049	10051	10052	10091
EMERSON	10011	10132	10137	10139	10141	10157	10140	10184	10185	10186	10187
	10188	10190	10192	10193	10194	10195	10196	10197	10198	10199	10200
	10201	10202	10355	10393	10319	10431	10380	10315	10311	10505	
EMPREX	10425										
ENVISION	10439	10358	10330								

Maker (Brand) Name	CodeNumber(5digit)List										
ENVIXION	10001										
EPSON	10364										
ERAÉ	10442										
ESA	10317	10318	10311								
FISHER	10013	10058	10393								
FUJITSU	10149	10228	10333	10334	10376						
FUNAI	10033	10045	10380	10311	10376	10452					
FUTURETECH	10045	10380									
GATEWAY	10310	10486									
GE	10001	10014	10015	10038	10057	10070	10083	10011	10121	10133	10141
	10145	10413	10319	10315	10489	10484					
GILBRALTER	10001	10011	10439	10315							
GO VIDEO	10443	10479	10476								
GOODMANS	10445										
GPX	10276										
GRADIENTE	10040										
GRUNDIG	10288	10289									
GRUNPY	10380	10376									
GVA	10278										
H & B	10301										
HAIER	10026	10322	10323	10324	10325	10326	10434	10373	10067		
HALL MARK	10011	10315									
HANNS G	10447										
HANNSPREE	10448	10449	10447	10263	10264						
HARLEY DAVIDSON	10451	10376	10452								
HARMAN KARDON	10034	10180	10181	10415							
HARVARD	10380	10453									
HAVERMY	10436										
HELIOS	10301										
HELLO KITTY	10319										
HEWLETT PACKARD	10456	10330	10458								
HISENSE	10266	10011	10279	10280	10373	10459	10462				
	10017	10011	10015	10016	10001	10018	10029	10043	10072	10132	10144
HITACHI	10147	10203	10204	10206	10207	10208	10210	10211	10368	10452	10543
HP	10357										
HUMAX	10143										
HYPERION	10011										
HYUNDAI	10460	10461									
I-INC	10463										
ILO	10091	10343	10362	10356							
INFINITY	10415	10148									
INFOCUS	10464	10364	10466	10467							
INITIAL	10356										
INKEL	10120										
INSIGNIA	10091	10366	10311	10417	10274						
JBL	10148	10415									
JCPENNY	10001	10011	10014	10015	10030	10035	10092	10132	10145		
JENSEN	10019	10234									
JVC	10261	10270	10038	10040	10079	10239	10550				
KAWASHO	10470										
KDS	10335										
KEC	10045	10380									
KENWOOD	10001	10229	10011	10439	10315						
KLEGG	10354										
KLH	10341	10303									
KLOSS	10002	10060	10001	10372							
KMC	10132										
KNOLL SYSTEMS	10467										
KONKA	10473	10475	10476	10477							
KOST	10478	10479									
KREISEN	10480	10479									
KT	10001	10045	10132	10140	10308						
KTV	10380	10439									
LG(GOLDSTAR)	10011	10093	10103	10113	10118	10132	10346	10315	10439		
LLOYD'S	10452										
LODGENET	10069										

TV

Maker (Brand) Name	CodeNumber(5digit)List
NAXA	10492
NEC	10001 10013 10022 10025 10030 10041 10057 10121 10125 10011 10235 10439 10315 10543 10405
NETTV	10486
NIKEI	10045
NIKKO	10001 10315 10439 10374
NIKO	10493
NOBLEX	10494
NORCENT	10373 10330 10495 10493
NORWOOD MICRO	10362 10498
NTC	10374
NUVISION	10502
OLEVIA	10011 10342 10535 10315
OLYMPUS	10503
ONWA	10045 10380
OPTONICA	10025 10034 10235
OPTIMUS	10485 10393 10504 10505
OPTOMA	10506 10448
OPTONICA	10436
ORION	10431 10376 10516
PANASONIC	10076 10010 10038 10057 10005 10148 10150 10169 10308 10359 10485
PENNEY	10001 10011 10413 10303 10315 10439 10484 10489 10388
PHILCO	10001 10003 10011 10030 10045 10057 10060 10061 10064 10065 10118 10132 10148 10415 10439 10315
PHILIPS	10148 10321 10011 10040 10060 10067 10132 10145 10001 10222 10003 10371 10415 10479
PILOT	10001 10011 10439 10315
PIONEER	10504 10024 10029 10031 10032 10011 10248 10254 10304 10001
POLAROID	10335 10338 10339 10340 10341 10303 10417 10362 10478 10301 10476
PORTLAND	10011 10132 10374 10315 10335 10424 10476
PROSCAN	10133 10249 10413 10262 10257 10268 10067 10269
PROTON	10059 10011 10103 10132 10165 10251 10315 10388
PROTRON	10507 10508
PROVIEW	10335
PULSAR	10011 10315
PUNEET	10425
PVISION	10442
QUASAR	10038 10057 10243 10308 10485
RADIO SHACK	10025 10045 10048 10011 10118 10132 10001 10235
RCA	10001 10004 10006 10011 10029 10030 10057 10083 10133 10145 10161 10171 10232 10371 10413 10484 10315 10256 10272
REALISTIC	10013 10025 10045 10048 10001 10011 10235 10393 10380 10315 10439 10543
REVOLUTIONHD	10354
ROCTEC	10237
RUNCO	10152 10153 10001 10250 10252 10336 10337 10439
SAMPO	10001 10059 10011 10486 10439
SAMSUNG	10305 10265 10001 10012 10051 10092 10011 10118 10124 10132 10145 10176 10221 10306 10542 10315 10439 10479 10408 10543
SANSUI	10431 10452 10516 10517
SANYO	10013 10026 10027 10037 10041 10054 10058 10078 10253 10393 10402 10484
SCEPTRE	10313 10067
SCIMITSU	10011 10315
SCOTT	10033 10045 10049 10011 10132 10380 10315 10376
SCOTCH	10315
SEARS	10011 10013 10021 10033 10035 10058 10078 10092 10132 10145 10244 10413 10415 10393 10303 10315 10111 10543 10376 10452
SEIKI	10259 10283 10284 10285 10286 10287
SELECO	10368 10430
SHARP	10260 10020 10025 10028 10033 10034 10132 10151 10235 10236 10361 10375 10436 10011
SHARPER IMAGE	10518
SHERWOOD	10120
SHOGUN	10011 10315
SIEMENS	10084
SIGNATURE	10069 10011
SIGNATURE 2000	10011
SIGNET	10519 10478 10520
SIM2 MULTIMEDIA	10430
SIMPSON	10001
SKYWORTH	10522
SOLARISM	10523
SOLE	10358 10483 10301 10479 10354
SONY	10043 10075 10117 10130 10067 10170 10238 10247 10309 10409 10452
SOUNDESIGN	10003 10033 10045 10011 10380 10315 10376
SOVA	10507
SOYO	10425 10463 10524 10525 10476
SPECTRICON	10103 10011 10388
SPECTRONIQ	10335
SQUAREVIEW	10311
SSS	10011 10045 10380 10315
STARLITE	10011 10380
STUDIO EXPERIENCE	10377
SUNBRITE	10528 10529
SUPERSCAN	10436 10530
SUPRE MACY	10002 10372
SUPREME	10409
SVA	10373 10479 10301 10532 10533
SYLVANIA	10001 10003 10008 10011 10060 10061 10064 10118 10126 10065 10145 10148 10155 10311 10355 10415 10439
SYMPHONIC	10380 10311 10452 10505
SYNTAX	10342 10535 10315
TANDY	10034 10436
TASHIKO	10537
TATUNG	10057 10063 10388 10458 10362
TCL	10256 10371 10267
TEAC	10379 10281
TECHNICS	10080 10076 10485

Maker (Brand) Name	CodeNumber(5digit)List
TECHNOL ACE	10376
TECHVIEW	10539 10541
TECHWOOD	10011 10388 10543
TELEMAGIC	10402
TEKNIKA	10001 10002 10003 10011 10030 10033 10036 10045 10069 10074 10092 10094 10132 10415 10380 10374 10315 10543 10376
TELEFUNKEN	10039 10047 10241 10242 10542 10543 10544
TELERENT	10069
TERA	10156
THOMAS	10452
TMK	10011 10315 10543 10378
TOSHIBA	10021 10013 10035 10041 10052 10063 10092 10142 10146 10178 10179 10393 10303 10464 10419 10517
TOTEVISION	10132
TRUTECH	10353
TVS	10431
ULTRA	10547 10508
UNIVERSAL	10014 10015
UPSTAR	10277
US LOGIC	10362
VECTOR RESEARCH	10001 10439
VENTURER	10315
VICTOR	10550
VIDEO CONCEPTS	10160
VIDIKRON	10255 10415
VIDTECH	10011 10315
VIEWSONIC	10363 10088 10330 10331 10349 10486 10530 10503
VIKING	10372
VIORÉ	10316
VISART	10551
VITO	10360
VIZIO	10011 10315 10351 10530
WARDS	10011 10014 10015 10025 10033 10061 10062 10064 10065 10069 10071 10132 10148 10001 10235 10415 10315 10439 10489 10543 10376
WAYCON	10303
WHITE WESTING HOUSE	10091 10319 10320 10327 10328 10329 10067 10431 10409
WINBOOK	10362
WOORYOUNG	10307
WYSE	10330
XOCECO	10552
YAMAHA	10001 10011 10439 10315
YORK	10011
ZENITH	10009 10069 10070 10090 10094 10431 10315 10374 10452 10516
ZONDA	10103 10388

